

98754 FLOOR STRIP SPINNER

- 1) PLACE LONG TUBE INTO BASE WITH NARROW END POINTED UP.
- 2) PLACE SHORT TUBE ONTO LONG TUBE.
- 3) PUT COTTER KEY THROUGH HOLE IN TUBE.
- 4) SLIDE NYLON WASHERS OVER TUBE AND ONTO COTTER KEY.
- 5) PLACE SPINNER SECTION ONTO DISPLAY- SMALL SPINNER FIRST.
- 6) USE ZIP TIES TO FASTEN SPINNER SECTIONS TOGETHER.
- 7) ADD SIGNHOLDER TO TOP OF DISPLAY.