

Assembly Instructions for Cedar or Mahogany Cart

1. Unwrap unit and remove from pallet.
2. Remove parts from Storage compartment
3. Place cart upside down.
4. Slip wheels onto axle, insert cotter keys through holes drilled in axle and bend to retain wheels.
5. Attach leg support at handle end with (2) 3 ½" bolts provided. Put 1 flat washer on each bolt, insert the 2 bolts through the pre drilled holes in the leg and then into pre drilled holes in cart body.
6. Reach inside from opposite end. Place flat washer and nuts on bolts. Tighten to hold leg secure.
7. Invert cart so two wheels and one leg support the cart.
8. If risers included, interlock 4 support pieces and place in bed of cart
9. Place 40 x 16 board on base riser.
10. Set pre-assembled small riser on top of base riser
11. If shelves included, place two support metal pieces on each side of cart approximately 30 inches apart. Add 40" shelves to unit and attach with screws provided.
12. If canopy, place end supports first, attach shelf tray second with the (4) 3" bolts provided. Put 1 flat washer on each bolt. Place bolts through pre drilled holes in cart and shelf tray. Reach inside and place 1 flat washer and 1 nut for each bolt. Tighten to secure.
13. Canopy attaches with (2) 3" bolts provided. Put 1 flat washer on each bolt; insert the 2 bolts one at a time into the pre drilled holes. Reach inside and place 1 flat washer and 1 nut on each bolt and tighten to secure.

Hardware:

- (10) 3" 7/16 bolts
- (2) 3 ½" 7/16 bolts for Leg Support
- (24) Flat washers
- (12) 7/16 Nuts
- (2) Cotter Pins for Wheels