



#WC-6 Assembly Instructions

Parts Include:

- 2 Sides - 44" X 11 1/4"
- 6 1X2 Strips - 32" Long
- 6 Crates
- 12 Bolts
- 1 Allen Wrench

No tools required except for the allen wrench that is provided.

1. The holes in the ends of the 1X2's correspond to the smaller holes in the edges of the sides. Attach the six 1X2's, three on the front and three on the back, to the sides using the bolts included.
2. Place the crates on the display as shown in the picture above. They are intended to rest on the frame angled toward the front. But they can also be flat in the display.
3. Save the allen wrench. Over time the wood frame may shrink and cause the bolts to loosen. If this happens, they will need to be tightened.