

Banner Stand



- Dowel holders attach to banner upright. Bottom holder (photo right) slides over upright and can be infinitely positioned along upright (note: dowel holder should face up – thumb screw at bottom). Use thumbscrew to tighten at desired height.
- Top Dowel holder (photo left) screws into the top of the upright.
- Dowel rods are inserted into pockets of banner.
- Banner with dowels are then slid into the dowel holders. Adjust bottom dowel holder and tighten to stretch banner.
- Upright is also adjustable using tightening clutch.



telescopic center pole

Bottom bar slides up & down adjustable height center pole
Ininitely Adjustable

