



**SPARE PARTS LIST  
CHEESE CUTTER**

<b>Heat Seal Part #</b>	<b>Description</b>
<b>2135001</b>	RUBBER FEET
<b>2185001</b>	O RING
<b>6501041</b>	COLLAR
<b>6501019</b>	PIN
<b>6501049</b>	KIT, SPARE PARTS INCLUDES:
	6501046 FRONT PLATE
	1970001 LOCK WASHER
	1911022 WING NUT
	6501011 WIRES
	6501048 LOCKING ROD
	1909006 WASHER
	1903057 1/4-20 X 5/8" SCREW
<b>6501015</b>	HANDLE
<b>6501079</b>	HANDLE NO LOCKING ROD
<b>6501011</b>	CHEESE WIRES PK OF 5 (14 3/4" long)