
## HUBERT®


3-Shelf Wire Station Cart

Item# 71593

## ASSEMBLY INSTRUCTIONS



- 1. Long Pole
- 2. Short Pole x 3
- 3. Middle Pole x 3
- 4. Short Grid
- 5. Long Grid x 2
- 6. Short Liner
- 7. Long Liner x 2
- 8. Plastic Clips x 24
- 9. Locking Caster x 4
- 10. Adjustable Foot x 3



## CASTER ASSEMBLY

- 1. Identify the 4 bottom poles (1 Long Pole and 3 Middle Poles) that have one black cap end and one end without insert (vs. top Short Poles that have black cap on one end and insert on other end). Casters should be installed on the end without insert.
- 2. Lay out a piece or 2 of cardboard on the floor for protection of the floor and the pole.
- 3. Hold the pole with black cap end toward the floor.
- 4. Hold caster with the stem facing the pole and the wheel toward the ceiling.
- 5. Line the closed back of the open split ring (on the stem of the caster) inside the pole.
- 6. Stabilize the caster with one hand and the pole with the other hand, trying to line them up as much as possible with the ring inside.
- 7. Gently tap pole on the cardboard until stem is completely inside pole.

