


ASSEMBLY INSTRUCTIONS

COMPONENTS



1. Top Shelf (no holes)
2. Bottom Shelf (holes)
3. Handle
4. Screw (M6x25) x 12
5. Leg A x 2
6. Leg B x 2
7. Swivel Caster x 2

8. Fixed Caster x 2
9. Lock Washer (M8) x 16
10. Hex Nut (M8) x 16
11. Caster Screw (M8 x 45) x 16

OPTIONAL (NOT INCLUDED):
Middle Shelf: Item# 32578(Sm), 42444(Lg)
Replacement Caster Kit: Item# 26990

TOOLS NEEDED (NOT INCLUDED):

Phillips Head Screwdriver

Rubber or Wooden Mallet

Wrench



Be sure to identify and confirm you have received all parts before assembly.

FOR YOUR SAFETY AND CORRECT OPERATION, PLEASE CAREFULLY READ ALL INSTRUCTIONS BEFORE USE.

NOTE: All of the information reported herein is based on data available at the time of printing. The factory reserves the right to modify its own products at any time without notice or incurring any sanction. Please verify with the factory for possible updates.

Improper assembly can cause personal injury and/or property damage.


Do not step into or on the cart, or use it as a toy.

Maximum Load = 550 lbs distributed evenly. Do not overload cart.




Use Rubber or Wooden Mallet to tap down parts to ensure they are seated properly before fastening them with screws.


- 1 Place Top Shelf(1) upside down and align Handle(3) as shown. Tap into place with Rubber Mallet.



- 2 Align Legs(5,6) as shown and secure with Screws(4).



- 3 Align Bottom Shelf(2) as shown and tap into place with Rubber Mallet.



- 4 Install Swivel Casters(7) closest to Handle, and Fixed Casters(8) opposite Handle. Each Caster is installed with 4 Caster Screws(11), 4 Lock Washers(9), and 4 Hex Nuts(10). Use a Wrench to hold Nuts in place while securely tightening Caster Screws.

