

Assembly Instructions

Thank you for purchasing a top quality
Masonways Wash Station
Please follow directions below to fully assemble
your wash station.


Soap Dispenser

- Open the latch on the side of the wash station
- Take the paper towel dispenser out of the inside of the tank
- Open the paper towel box
- Take the soap dispensers out of the inside of the paper towel box
- Affix the soap dispensers by removing the lid and aligning the plate on the wash station and the dispenser, slide down until you hear click.
- Fill with desired soap and re attach lid



Paper Towel Holder

- Take the 4 screws out of the mesh bag
- Align the paper towel dispenser on the top of the wash station
- Screw in the screws with a Phillips head screw driver
- Fill with 2 packets single fold paper towels (Georgia Pacific 23504)



*Soap dispensers may differ based on availability.

*Two packs of single fold paper towels (Georgia Pacific 23504)



Amy.fabrini@masonways.com
Crystal.suarez@masonways.com

1-800-837-2881
Masonways.com