

# Fill/Empty Instructions

Please follow directions to fill and empty

## Fill instructions:

1. Undo latch and Open lid
2. Find port in the freshwater tank (outer tank)
3. Using a garden hose or other hose pour in the freshwater



## Emptying instructions:

1. Undo latch and Open lid
2. Find the wastewater tank (inner tank)
3. Use a **Shop Vac** to remove dirty water. Dispose of dirty water in an outdoor drain or contact a professional for removal such as a Porta Potty service.



## Specs:

Rhino Hand Wash Station Dimensions		
Length	34.5"	87.63 cm
Width	26.5"	67.31 cm
Height	51"	129.54 cm
Weight	120 lbs	54.43 kg
Filled Weight	770 lbs	349.26 kg
Grey Water Tank	47 gal	177.91 L
Fresh Water Tank	45 gal	170.34 L

Rhino Mini Hand Wash Station Dimensions		
Length	15"	38.1 cm
Width	27"	68.58 cm
Height	55"	139.70 cm
Weight	83 lbs	37.64 kg
Filled Weight	495 lbs	224.52 kg
Grey Water Tank	25 gal	94.63 L
Fresh Water Tank	24 gal	90.84 L