

## REPLACING INK ROLLER (PROLINE)

### PROLINE S/M



**STEP 1**  
Press the handle lever to lift up the ink roller holder.



**STEP 2**  
Pull out the ink roller bracket, remove ink roller from bracket.



**STEP 3**  
Clip the ink roller bracket onto new ink roller.



**STEP 4**  
Fix the ink roller bracket back to the ink roller holder and push in to close.

### PROLINE L/ XL/XXL



**STEP 1**  
Pull to open the front cover.



**STEP 2**  
Press the handle lever to lift up the ink roller. Pull out the ink roller.



**STEP 3**  
By pressing the handle lever, attach the new ink roller onto the ink roller suspension. Ink roller facing top.



**STEP 4**  
Release the handle lever and close the front cover.