

At the end of the day, after the bowl has been cleaned follow these three steps:

- 1 Look at the bottom of the bowl for chocolate. It should be clean.
- 2 Look in the motor compartment for chocolate, it should be clean.
- 3 Turn the metal driver with your fingers. It should turn very easily.



If you see chocolate on the metal driver or if it is difficult to turn you should replace your Seal and Bearing kit. There should not be chocolate on any of these areas.

If you have any questions please call Sephra at (877) 617-8803.

Sephra fountains are the only electrically & sanitation certified fountains in the industry. The electrical certification requires a thermal switch be installed in each motor. The thermal switch will shut the motor off if it begins to overheat. Once the motor cools down it will start back up again, **but the fountain should be serviced immediately.**

SEPHRA®

11035 Technology Place, Suite #100
San Diego, CA 92127 • 858-675-3088

Scan the QR Code
Watch the Video

Scan this QR Code and watch the "Quick and Easy way to maintain your fountain" video.

