CLEANING AND HANDLING INSTRUCTIONS

Break down unit by removing the back pin and pulling slider and chute out of the canister. Remove front pin that supports the portion control baffle as well.

Plastics ARE NOT DISHWASHER SAFE!!!! We recommend Hand washing with a mild detergent (i.e.: JOY) and soft sponge and rinse, air dry or use a soft cloth. For additional polishing off scratches, we recommend the use of our Clean Kit. (Cal Mil part # 218)

> We do not recommend our items to be exposed to extreme temperatures. Especially our Glass and Plastic items, it may cause them to warp or crack.

CAUTION Avoid use of Alcohol, Ammonia or Chemical based Cleaners...

DO NOT USE ABRASIVES

SANITIZING SOLUTION

Use 1 table spoon of bleach per gallon of water. **Must check manufacturer's instructions as everyone has different formulas**