

Gondola Starter Unit Includes:	
(2) Upright Posts	(1) Top Spanner
(2) Kickplates	(1) Lower Spanner
(2) Base Shelves	(1) Center Spanner
(2) Back Panels	(All) Finish Trim
(4) Base Shoes	
*Create a stand-alone Gondola by using one Gondola Starter Unit only. Upper shelves are added and sold separately.	

Wall Starter Unit Includes:	
(2) Upright Posts	(1) Top Spanner
(1) Kickplates	(1) Lower Spanner
(1) Base Shelf	(1) Center Spanner
(1) Back Panel	(All) Finish Trim
(2) Base Shoes	
*Create a stand-alone Wall Unit by using one Wall Starter Unit only. Upper shelves are added and sold separately.	

Endcap Unit Includes:	
(2) Uprights	(1) Top Spanner
(2) Base Shoes	(1) Lower Spanner
(2) Back Panels	(1) Center Spanner
(1) Kickplate	(All) Finish End Trim
(1) Base Shelf	
*Create a stand-alone endcap by using one Endcap Unit only. Upper shelves are added and sold separately.	

Gondola Add-On Unit Includes:	
(1) Upright Post	(2) Base Shoes
(2) Kickplates	(1) Top Spanner
(2) Base Shelves	(1) Lower Spanner
(2) Back Panels	(1) Center Spanner
Create a Gondola Run by using one Gondola Starter Unit + the desired number of Gondola Add-On Units	

Wall Add-On Unit Includes:	
(1) Upright	(1) Base Shoe
(1) Kickplate	(1) Top Spanner
(1) Base Shelf	(1) Lower Spanner
(1) Back Panel	(1) Center Spanner
* Create a wall run by using one Wall Starter Unit + the desired number of Wall Add-On Units. Upper Shelves are added and sold separately.	

Notes
Upright Post - Heavy-gauge, high-quality steel component; slotted 1" on center.
Kickplate - Floating feature fits flush against uneven floors; for easy cleaning, snaps in or out without removing base shelf. Electrical knockouts.
Base Shelf - Lock-in tabs ensure quick installation and precise alignment.
Back Panel - High-density 3/8" pegboard fits flush to face of Upright Post.
Base Shoe - 5"H with exclusive I-beam design; welded, high-strength steel parts ensure maximum load capacities; snaps securely into Upright Post.