




Outperform every day.™

# Instruction Sheet

## Gravity Fed Cup Dispenser

### Mounting

- Wall Mount: See below.
- Rotating Stand: See Rotating Stand Assembly Instructions.




Item No.	Accommodates Cups with Rim Diameter
PLC-1	2¼ - 2⅞" (5.7 - 7.3 cm)
PLC-2	2⅞ - 3½" (7.3 - 8.9 cm)
PLC-3	3½ - 4⅞" (8.9 - 10.5 cm)
PLC-4	4⅞ - 4⅞" (10.5 - 12.4 cm)

### Wall Mounting Instructions


1. Drill the mounting holes for the brackets.
2. Install the mounting screws into the brackets.
3. Align the brackets on dispenser with the wall-mounted brackets.
4. Slide the dispenser onto the wall-mounted brackets.

## Load Cups


**1** Loosen the five wing nuts.  
Do NOT remove.




**2** Partially load cups.



**3** Pinch in sides until cups are held in place. Tighten last wing nut. Verify cups dispense one a time.



**4** Tighten the remaining wing nuts.



**5** Load remaining cups.



www.vollrath.com

### The Vollrath Company, L.L.C.

1236 North 18th Street  
Sheboygan, WI 53081-3201 U.S.A.  
Main Tel: 800.624.2051 or 920.457.4851  
Main Fax: 800.752.5620 or 920.459.6573  
Customer Service: 800.628.0830  
Canada Customer Service: 800.695.8560

### Technical Services

techservicereps@vollrathco.com  
Induction Products: 800.825.6036  
Countertop Warming Products: 800.354.1970  
All Other Products: 800.628.0832