

## Sani Cart Assembly Instructions

Suggested Tool: Rubber Mallet

1. Assemble (B) & (F), then attach plastic collars (A) to 7th notch from bottom. Repeat for all four posts.
2. Place basket (G) onto posts, sliding all the way down and tapping securely into place.
3. Slide 3 of the shelves (C) onto posts and let rest at bottom.
4. Clip collars (A) onto all 4 posts at top notch and place the 4th I shelf on top.
5. Raise up one I shelf from bottom, clipping a plastic collar (A) onto all four posts at the 18th notch from the top.
6. Repeat step 5 for the two remaining shelves (C), but placing the collars (A) on the 36th notch from the top and then the final shelf collars (A) at the 54th notch from the top. Lightly tap all shelves into place with mallet.
7. Hang grid panels (D) onto top 3 shelves (C). Each shelf has one on each side and two in the middle.
8. Attach casters (H) and hang pegs (K) where needed.

