



ALIMENTO CALIBRATION INSTRUCTIONS

1. Power the scale on.
2. Press the **"TARE"** button in ½ second intervals 3 times and the 4th time held down, making a total of 4 presses (Example: Must be quick presses 1, 2, 3 & hold on 4th) until the LCD displays a digital range within **"-4000 – 12000"**.
3. Press the **"TARE"** button; the LCD will now display the required weight for calibration **"6000g"**.
4. Gently place 6000g (6 kg) weight onto the scale platform.
5. After your platform is stable from any movement, press the **"TARE"** button. The LCD will briefly display **"CAL"**, and then **"PASS"** for successful calibration. (**"EEEE"** will appear if calibration failed.)
6. Calibration is now completed; power the scale off and restart.