

FRYER PUCK[®] DIRECTIONS SHEET

Low Foaming Concentrated Fryer Boil-Out Tablets

FRYER PUCK[®] BOIL-OUT DIRECTIONS - Wear high heat protective rubber gloves and safety glasses. Wipe out heavy sediment from the frypot. Drain oil for filtering or for disposal and remove from the fryer area. Fill frypot with water to the top fill line. Add FRYER PUCK[®] Concentrated Fryer Cleaner Tablet(s) according to size of fryer Ratio: 1 Tablet (4 oz.) - 40# fryer, 2 Tablets (8 oz.) - 75# fryer. Set fryer to BOIL OUT mode or 195°. Boiling at higher temperatures will cause overflow. Continue boiling for 15 minutes. Turn off heat. Drain BOIL OUT water from frypot. Prepare a vinegar solution (1 cup vinegar to 1 gallon of water). Thoroughly rinse all frypot surfaces, baskets and accessories with the vinegar solution. Completely wipe vinegar solution from frypot surfaces, baskets and accessories to avoid contaminating the oil. Return oil to frypot for filtering or refill the frypot with fresh oil.

TO CLEAN FRY BASKETS AND FRYER ACCESSORIES: PLACE THEM IN THE FRYER POT DURING BOIL OUT.

NOTE: Deep Fryers should be boiled out at least once a week or as often as necessary to maintain clean cooking oil!

SAFETY PRECAUTIONS - DANGER: May cause burns. May be harmful or fatal if swallowed. Keep Out of Reach of Children. Avoid contact with eyes and mucus membranes or prolonged contact with skin. **CORROSIVE** - Contains Sodium Hydroxide. **FIRST AID: EYES:** Flush immediately with lots of running water for at least 15 minutes holding eyelids open. Get medical attention. **SKIN:** Product is alkaline. Wash with water. Continue to rinse until no longer slippery. **INTERNAL:** Drink large quantities of water or milk. **DO NOT INDUCE VOMITING.** For further information, Consult MSDS. Do Not Mix with Other Cleaning Agents or Chemicals.

For Health & Safety Emergency Only: 1-800-255-3924

Discovery Products Corporation
13619 Mukilteo Speedway #1180 • Lynnwood, WA 98087
Toll Free: (877) 822-8500 • Ph: (425) 267-9577 • Fax: (425) 267-9156
Email: info@discoveryproducts.com • Website: www.discoveryproducts.com