



## RTA CUBE ASSEMBLY INSTRUCTIONS

### TOOLS & HARDWARE REQUIRED



#2 Phillips Screwdriver



Rubber Mallet



Cordless Drill (Optional)

### BASE KIT CONTENTS



(2) Cube Panels

Box 1 of 3



(2) Cube Panels

Box 2 of 3



(1) Cube Top



(20) Confirmat Screws



(20) Screw Caps



(8) Dowels

Box 3 of 3

### ASSEMBLY

#### PANEL INSTALLATION

**NOTE:** Assemble the base kit first, then position it to accept the cube panels.

1. Make sure the (4) dowels are inserted into the base top by tapping them into position with a rubber mallet. (See Figure 1)
2. Locate the red bag of hardware.

**NOTE:** Strongly recommended for two people to complete steps 3 through 4.

3. Install two panels together onto the dowels. Locate the holes on the bottom of the panels and set them onto the dowels. (See Figures 2 and 3)
4. Attach panels together with the confirmat screws into the pre-drilled holes, using the cordless drill or #2 Phillips screwdriver.

**NOTE:** Do not fully tighten screws until all the panels are in place. Once all of the panels are in place, tighten and snug the screws.

5. Install remaining panels to complete the unit. (See Figure 4)

Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



#### TOP INSTALLATION

6. Place the cube top onto the panels with the supplied dowels. (See Figure 5)
7. To cover the exposed screw heads, peel the decorative screw caps to expose the sticky back and carefully center and cover the screw heads. (See Figure 6)

\_\_\_ HARDWARE  
 \_\_\_ CASTERS  
 \_\_\_ INSTRUCTIONS  
 \_\_\_ INITIALS  
 \_\_\_ MONTH/DAY